Model No. 640
AA Batteries

Model No. 641
C & D Batteries

The Battery Interrupter - #640 & 641

User's Guide

The small device with big benefits! With a little device called the *Battery Interrupter* a battery-operated toy (or a battery-operated device) can easily be adapted to be operated with one of the many switches available in the marketplace.

The *Battery Interrupter* is easy to install and it can be easily removed – to change a battery, to fix the toy/device or to use with another product that functions with the same size batteries!

This small economical device will bring joy and learning into the lives of younger or older children. It can make life more productive for *all* ages!

***Battery Interrupters* are available in four models:**

#640 "AA" Interrupter with 1/8" Jack
#641 "C" and "D" Interrupter with 1/8" Jack

<u>Adapting a Toy with a Battery Interrupter</u>:

- **Everything you need: A** battery-operated toy/device, batteries, a switch, and the *Battery Interrupter*

- **Procedure:**

1) Position the disc of the *Battery Interrupter* against the wall of the battery compartment on the negative end (where the negative side of the battery will go)
2) Make sure that the small "silver bump" (**For Model 641 Only**) is facing outward into the battery compartment.
3) Insert the battery into the compartment. If it is a really tight fit, you may want to insert the *Battery Interrupter* and the battery simultaneously so that they will slide in better.
4) The small "silver bump," (**For Model 641 Only**) if installed correctly, should fit into the dent on the negative side of the battery.
5) Close the lid of the battery compartment (if applicable).
6) Plug a switch into the Jack at the other end of the *Battery Interrupter*. If you are using an adapter, make sure that it is in tight leaving NO gaps.
7) The toy/device can now be controlled with the switch!

NOTE:

- The Battery Interrupter will not work with every battery-operated toy/device. It will work best with toys/devices that only require a simple ON/OFF switch to activate their features.

- You only need one battery interrupter per battery compartment. Example: even if the battery compartment includes 4 batteries, you still only need one *Battery Interrupter.*
- Do not submerge in water

Rev 5/23/06