Drumming Bunny #445

USER'S GUIDE

Rat-a-tat!

She walks and plays her drum while moving her head from side to side. Size: 13"H x 4"H. Requires Capability Switch and 2 D Batteries

Operation:

1. Drumming Bunny requires 2 D batteries (not included) to operate. Alkaline batteries must be used (e.g. Duracell or Energizer Brands). Do not use rechargeable batteries because they supply a lower voltage and the unit may not perform as well. Never mix old and new batteries together or different brands or types together.

2. Locate the battery compartment on bottom of Drumming Bunny's feet. Simply turn the latch to one side to open the compartment and install 2 D batteries paying close attention to proper battery polarity. Close the battery compartment cover.

3. Connect Drumming Bunny to any external capability switch (not included) via the jack located at the end of Drumming Bunny's cord. Drumming Bunny is equipped with a 1/8" jack for use with external capability switches with a 1/8" plug. Make sure you have a tight connection. There should be no gaps.

4. Actuate your external capability switch and Drumming Bunny will come to life!

5. Drumming Bunny will remain on while the external capability switch continues to be actuated. Once you release the external capability switch, there will be a brief delay and then Drumming Bunny will turn off.

Troubleshooting:

Problem: Drumming Bunny does not function correctly.

Action #1: Replace the batteries paying close attention to proper battery polarity.

Action #2: Make sure that the connection between the external capability switch and the jack is TIGHT. There should be NO gaps.

Action #3: Try your switch with another switch operated toy/device in an effort to rule out your switch as the source of the problems.

Care of Unit:

If you will not be using Drumming Bunny for an extended amount of time, we recommend removing the batteries.

Do not submerge the unit in water, as it will damage the electrical components. Drumming Bunny is surface washable only.