

Instructions for 10196 Accessory Strap Kit

Tools Required

Phillips Screw Driver

INSTALLATION INSTRUCTIONS

STEP 1: Fasten Male Snap Halves as shown.

Use a Phillips screw driver to screw in 4 Male Snap Halves into the pilot holes at these locations.



Male Snap Half



STEP 2: Attach the (2) straps by fastening to the Male Snap Halves.

Paper Straps

