

1. Loosen straps and place involved foot in splint
2. Secure three clasps and adjust to desired comfort level
3. Rest foot on heel, removing weight from ball of foot
4. Adjust side straps to desired degree of flexion