SQUARE GLOW





Powered by **JSG**

CONGRATULATIONS ON YOUR PURCHASE!

This user manual will help you assemble and operate your new SquareGlow alarm. Be sure to read **ALL OF THE INFORMATION** in this manual before using SquareGlow.

Main Features



52 Ring Tones

Volume Control

- IP 44 waterproof transmitter
- Operates up to 600 feet away
- Easy to add additional transmitters
- Low power consumption



You should find each of these items in your SquareGlow box:

- 1. Doorbell
- 2. Phone Signaler
- 3. 2 Receiver(Flasher)
- 4. 4 Screws
- 5. RJ11 Wire
- 6. 12v 23a battery





Remove all packing material, then inspect each item for any accidental damage that may have occurred during shipping.

(!) What you should know before installation


1. Doorbell's signal can be affected by metal, walls, concrete and interference from other electronics.

2. Determine the operating Range you want before installation.

3. Flasher only supports DC 5V 2A adapter or 3 AA batteries.


Installation Methods


You can put it on the desk ,or hang it up as following method:



Operating Instructions

Please read the following diagram of button functions before operation:





Attention before operating

Pull out the insulating strips rom the phone signaler.

Insert the RJ 11 wire for phone signaler.

Equip flashers with batteries or DC 5V adapter.

Don't use other adapters on flasher.

Pairing Transmitters with Flashers

Pairing LED colors:

1. Turn on flasher.

2. Please ensure that the light on flasher is turned off after you turned off the power.

3. Short press... \rightleftharpoons to select the LED color you want.

4. Long press... \square to launch pairing signal until flasher is flashing.

- 5. Press the doorbell or phone signaler button quickly.
- 6. Congratulations on your success.

if it is not working, please try again.

Pairing ringing tones:

1. Turn on the flasher.

2. Please ensure that the light on flasher is turned off after you turn on the power.

3. Short press... \checkmark to select the ring tone you want.

4. Long press... \square) to launch pairing signal until the flasher is flashing.

- 5. Press the doorbell or phone signaler button quickly.
- 6. Congratulations on your success.

if it is not working, please try again.

Attention after pairing:

- 1. One flasher can pair with unlimited signalers.
- 2. One signaler can pair with countless flashers.

3. User can long press \int to wipe all records, then begin pairing again.

Warranty

For further information on warranty and claims, please visit **www.squareglow.com**. For returns or repairs, please send your products in its original box to ensure a smooth return transition.

#