

Light Use Frame 6' - 1 BAY - Residential
model: LT USE FRAME

The Light Use Frame is 50" wide at the top and at the bottom it is 7' wide above ground. It is 7½' tall and 8' from front leg to back leg above ground. This is an above ground set and is not for regular swinging. You need to swing between the A frame. It includes a crossbeam for extra support. The frame weighs only 60 lbs. It also comes with stakes so that it can be placed on grass or dirt surfaces. Optional feet are available for inside use to help prevent floors from marring.

*This will ship by a trucking company, additional freight may apply.

PARTS INCLUDED ARE:

EFP - End Frame Parts (94) / Cpipe - Crossbar Pipes (2) / Lpipe - Pipe for Legs 8.5' Long (4) / Tpipe - Pipe for Top Rail 4.17' Long (1)

Installation, Safe Use and Maintenance Instructions

IMPORTANT: To keep children safe from harm, follow these precautions and instructions when installing, using, or maintaining this playground equipment.

Installation: Lay out all the pieces on the ground. Arrange them the way they will eventually connect as the finished assembly, approximately, two to three feet from where the set will set into the ground. You should have your holes dug 2 ft deep to place in the galvanized pipe legs. Be sure to cement them in well before letting your children play.

Slide the 2 triangular pressings onto the top bar. Do not secure yet. Bolt end pressings to top bar using bolts and locknuts. With top bar upside down, bolt legs to end pressings using bolts, washers, locknuts. Stand frame on its legs and bolt on crossbars with bolts, washers and locknuts. Push end caps onto crossbars. Position triangular pressings to take swing accessory and secure with U bolt, rubber strip, washers and locknuts. Tighten locknuts as pressings must not move. Suspend equipment from triangular pressings using cap square bolts, flanged bushes and locknuts. Do not over tighten. Bolt stakes to end of legs using bolts, washers and locknuts. Tighten all nuts.

If using S-hooks you will need to make sure the S-hooks are closed to within .04 to meet ASTM safety standards. To do this you will need to use our S-hook pliers or a regular pair of channel lock pliers.
WARNING: Once the S-hooks have been opened they will have to be replaced to avoid injuries from coming open and/or breaking. Make sure that the shackles used are tightened and if you use the shackle swing hangers for the chain that these also are tightened. Inspect regularly or use Loctite® to make sure bolt is still tight.

Safe Use: This is for children 5-12 year olds only. Not for Adults. Adults should supervise children at all times. Do not allow children to stand on or use unsafely. Do not allow it to be used if damaged.

Maintenance: Do the following to reduce the chance of serious injuries. Check monthly for cracks, rust, missing rivets, open S-hooks or evidence of vandalism such as cutting, metal showing through the material or bent seats from children standing on them. Tighten and lubricate all metallic moving parts per manufacturer's instructions. Check all protective coverings on nuts, bolts, pipes, edges, corners and all moving parts including swing hangers, swing seats, ropes, cables, chains and shackles. Replace as needed. Make sure there are no exposed footings, anchoring devices, rocks, roots, holes or any other obstacles in or around playground equipment. In high use areas these inspections should be done more frequently. Clean with mild soap and water when you do the monthly maintenance checks.

Any damage from vandalism, abuse or misuse VOIDS all warranties.

BASIC POLICY AND PROVISIONS

Playset's are shipped via Curbside Shipping. Delivery will be done by a tractor/trailer (a big truck). The driver is only responsible for delivering (driving) the order to your curb. A delivery appointment is scheduled by the freight company via the phone number (s) you provide in your order. No delivery will be made unless an appointment is set. The delivery person requires your assistance in unloading the order. Any additional

services, such as two-man delivery or inside delivery are not included in the price of the freighted item. The cost of these additional services varies from city to city. They usually cost between \$50.00 and \$150.00 extra. You may purchase the additional services directly from the freight carrier when delivery is scheduled. It is a good idea when you make your appointment, to have the freight company call you 30 to 45 minutes before delivery so as to avoid having to wait for the driver to show up.

RECEIPT OF SHIPMENT/CUSTOMER RESPONSIBILITY

Before signing for your order, check to see that you are receiving the same number of cartons, bundles, and loose pieces etc., indicated on your receipt.

Note any shortages or visible damage on your receipt and have the driver note these also.

Damage which is found after you unpack the shipment (concealed damage) must be reported to Customer Service immediately. Please closely inspect your shipment! Most freight companies allow 10 days from receipt to report concealed damage.

NOTE: If you discover damage of any kind, DO NOT DESTROY ANY ORIGINAL SHIPPING CARTONS.

LOSS OR DAMAGE IN SHIPMENT

Customer signing bill of lading at time of delivery is our receipt from the carrier. We therefore, are released of all responsibility for loss or damage in transit. Merchandise, as received by you, should be carefully checked against the freight bill to be sure delivery of all items has been made.

Count the shipment and inspect for damage. If shipment is not delivered to you in good order and in accordance with the quantity shown on the Freight Bill of Lading, please note the shortage or damage on the Freight Bill before you sign for the shipment. Please contact your sales representative to advise the company of the shortage or damage.

As soon as possible after delivery, open all cartons and inspect for concealed damage. If you do have shortages or damage in cartons, please contact your representative's office immediately so replacements can be made.

Do not throw away your copy of the Freight Bill. Any damaged or missing pieces not signed for as such on the Freight Bill of Lading will be replaced at the replacement cost, and freight charges will be charged to deliver the merchandise to your site.

Please note that the driver is obligated to bring your merchandise to the end of the trailer. It may then be advisable to have someone on hand to assist in unloading the merchandise as these systems come on 8' to 12' long pallets and weigh a minimum of 500 pounds.