

Osaki

Foot Sauna

(OS-F2)



Rated Power	160W
Voltage	110V
Power Plug	10A, 125V

Warning

1. Blood circulation disorders, such as diabetes, high blood pressure, and heart disease, or sensitive skin, can heighten the risk of low-temperature burns, presenting a potential danger.
2. Avoid sleeping between uses, as even healthy individuals are at risk of burns. Falling asleep during use is strictly prohibited.
3. This product is a dry sauna inside. It is not intended for use with water inside.


Precautions for handling

1. Prohibit use in humid areas, wet floors, bathrooms, etc., as this wood and electric product must stay dry.
2. After use, disconnect the power plug, cover it with a towel, and store the device.
3. Exercise caution to prevent contact with children or pets.

How to use the product

1. We recommend wearing casual clothing.
2. The effectiveness increases when used after consuming 1-2 cups of warm water or a fermented beverage.
3. It is recommended to use after powering on for approximately 20 minutes.
 - Pull the wooden board cover towards you during preheating to contain heat. Factory setting is 131°F/60 minutes; refer to the instrument panel instructions for adjustments.

How the instrument panel works



1. Plug the product into an outlet
2. When you press the power button, the product starts working. Upon shipping, it is set to 131°F for 60 minutes. The temperature blinks twice before displaying the current temperature inside the container.
3. If you simply press the power button and use it without adjusting the temperature or time, the temperature will plateau at 131°F, and the timer will cease after 60 minutes.
4. The temperature can be adjusted from a minimum of 65°F to a maximum of 149°F in increments of 34°F by pressing the + and - buttons.
5. The time can be set from 1 to 99 minutes and adjusted in increments by pressing the + and - buttons
6. After use, press the power button to turn it off, and disconnect the power plug.

Cleaning the product

1. If moisture enters the container, wipe it off with a dry towel, and dry it in the shade.
2. Use a vacuum cleaner to remove foreign substances, please.
3. Prohibited: the use of bleach, dye, paint, etc.
4. Strictly prohibit the disassembly of the product as safety cannot be guaranteed.

Electrical management of products

1. Lightly press the button on the instrument panel. Pressing too hard may prevent the power from turning on.
2. After use, make sure to disconnect the power plug.
3. As this is an electrical product, avoid using wet towels, etc., as there is a risk of electric shock.
4. If the power cord is damaged, contact a qualified professional or service center.
5. Do not disassemble, repair, or modify the product arbitrarily. There is a risk of fire and electric shock.

- **Outlet only**
Use only an outlet rated at 10A or higher and 110V AC.
- **Prohibited for use with voltages other than 110V**
Do not use for voltages other than 110V AC.
- **plug cut off**
When maintenance is necessary, be sure to unplug the power plug.
- **Power cord management**
Unplug the power plug when unattended or during sleep.
- **Do not use in wet locations**
Do not wash with water or use in a bathroom.
- **The provision of AS services.**
When replacing the power cord, please contact an expert or an after-sales service center

- Never allow anyone other than a repair technician to disassemble, repair, or modify the product.
* It may cause fire, electric shock, or injury due to abnormal operation.
- It may cause fire, electric shock, or injury due to abnormal operation and abnormal heat generation due to overload.
- Washing with water or using in wet places may cause fire or electric shock.

Warranty

1. We provide a warranty for our products in accordance with consumer damage compensation regulations.
2. If there's a performance issue during normal use, we'll repair the product for free within the warranty period.
3. The quality warranty period is one year from the date of purchase.
4. If the quality guarantee period has expired, repair costs incurred due to natural disasters or consumer negligence will be charged.