Cordless Super-Switch (H-2)

The purpose of the Cordless Super-Switch is to function as a mouse-click for special sofware, or to allow other switches to do the same. 2 switch inputs along its side allow connection of other switch(es) to perform just about any action for any software (default is left/right click for Windows, left/control-click for Mac). Also, the Super-Switch functions as a regular switch for adapted toys and appliances!

If you're using other software than ours, it is very important that you confirm what it is actually *looking* for, when it refers to "switch." All our software looks for mouseclicks when we refer to a "switch." See Software Installation below if your software is looking for something else.

Hardware Installation for Windows

Plug the receiver into any available USB port, while your computer is on. Windows 2000/ME/XP/Vista should detect it and install without any help from you. Windows 98 (Second Edition) will probably ask you to put in your Windows CD (the one that came with your computer). Do so and wait about 10 seconds for the CD to 'mount', then click OK.

Hardware Installation for Macintosh

You can plug the small receiver into any available USB port, either directly in the computer or in the keyboard, at any time. Windows 2000, XP, & Vista will take a moment to auto-install the necessary drivers. No action on your part should be necessary.

On the bottom of the Super-Switch are 2 holes. The one closest to the edge is an off/on slide switch, and towards the dot is ON (you'll need to use a pen/pencil point to reach it, and #2 below).

Tuning the Receiver to the Transmitter

My Super-Switch comes with the AAA battery installed for you, but you might need to 'tune' the receiver to the transmitter.

1) With your computer ON and the Super-Switch ON, and the little receiver plugged into a USB port, press the little button at the end of the receiver and a light will start to blink slowly.
2) On the bottom of the Super-Switch, press/release the recessed, small brown button.
3) The light from #2 should stop blinking.

Now your Cordless Super-Switch should function as a mouseclick. The easiest way to test this is simply to use your mouse to point to the Start button (in Windows) or the Apple menu (on a Mac) and press the switch. The menu should appear/disappear with each switch activation.

Turn the Super-Switch OFF for toy/appliance use.

Software for Programs That Don't Look for a MouseClick

Remember, to control other company's special needs software, you need to know what that software is expecting as the "switch." Use our free SwitchHopper (Windows or Mac OS 9) or SAM-X (Mac OS X) software that is on our CD or our website, to set up the Cordless Super-Switch for those programs that are looking for a <space> or <control-enter> or <whatever> in their switch software. The Cordless Super-Switch can be set to 'send' any keystroke/key-combination or mouse button action to your computer.

For returns/repair, you must contact us and obtain an RMA!