

MAINTENANCE OF TFH BUBBLE TUBE/WALLS

DO NOT USE any premoistened wipes, disinfecting sprays or any alcohol, ammonia, peroxide or bleach based cleaners on the Bubble Tube/Wall. This will deteriorate the acrylic and result in spider cracks which will cause leaks in the Bubble Tube/Wall. Use **ONLY** Bubble Tube Cleaner (9BCC) on the outside of TFH Bubble Tube/Wall.

TFH USA recommends that you use Gold Bond Hand Sanitizer when touching our Bubble Tube/Walls. Any of the alcohol-based hand sanitizers will transfer that alcohol to the Tube/Wall resulting in spider cracks and leaks.

Regular maintenance of the TFH Bubble Tube/Wall includes...

MONTHLY:

Add a capful of **BUBBLE TUBE ADDITIVE (sold separately - 9BCCA)** monthly. You will receive a starter bottle with the purchase of your Bubble Tube/Wall. All of this is to be used in your new Bubble Tube/Wall at the time of setup.

EVERY FOUR TO FIVE MONTHS:

Empty the entire contents of the Bubble Tube/Wall with the **DRAINAGE PUMP (sold separately - 9BCPUMP)** every four or five months. Remember to add an extra capful of anti-algae solution (Bubble Tube Additive, see above) every time you change the DISTILLED water in your Bubble Tube/Wall.

CLEAN INSIDE OF BUBBLE TUBE ONLY:

Empty entire contents of the Bubble Tube with Drainage Pump. Add a couple inches of DISTILLED water and a drop or two of Dawn™ dishwashing detergent to the inside. Use a dedicated rag mop to clean the inside of the Tube. Rinse thoroughly with DISTILLED water several times to remove all soap residue. We recommend you do this at a minimum yearly or if it will not be used for 30 days or more.

CLEAN OUTSIDE OF BUBBLE TUBE/WALL:

Recommended EXTERIOR disinfectant: **BUBBLE TUBE CLEANER (9BCC)**. This is a hospital-grade disinfectant that has been tested on our Bubble Tube/Walls and will not crack the acrylic. This cleaner may leave a cloudy residue which can be cleaned off the water and dried with a soft cloth. To restore the shine to your Bubble Tube/Wall, we recommend a vinegar/water solution.

REFILL BUBBLE TUBE/WALL:

While Bubble Tube/Wall is running, fill Tube/Wall with DISTILLED water only. Adding tap water, even a small amount, will contaminate the Bubble Tube/Wall and greatly increase the chance of algae growth.

Gallons of DISTILLED Water To "FILL LINE"

2M Tube	9 gallons (approx.)
1.75M Tube	8 gallons (approx.)
1.2M Tube	5.5 gallons (approx.)
Budget Bubble Tube	3 gallons (approx.)
Tabletop Bubble Tube	1.5 gallons (approx.)
Bubble Wall Short	1 quart (approx.)
Bubble Wall Tall	2 quarts (approx.)
Infinity Wall Short	1 quart (approx.)
Infinity Wall Tall	2 quarts (approx.)

Keep extra DISTILLED water on hand to replenish when water evaporates (naturally occurring). If water is 2-3" below "FILL LINE" check base for leaks and call us immediately. **DO NOT TURN OFF BUBBLE TUBE/WALL.**