


MATTRESS SET-UP GUIDE


1 UNBOX

Lay the box on its side to remove mattress.




2 CUT OUTER WRAPPING

Using scissors, carefully remove the plastic outer wrapping material. **DO NOT** cut outer wrapping with a knife as it could result in damage to your mattress.



3 UNROLL

Roll out the compressed mattress on the bed surface. Glideaway mattresses require a strong support system - do not place mattress directly on a steel bedframe.



4 CUT BAG AND EXPAND

Using scissors, carefully cut the plastic mattress bag at the end. Your mattress will instantly begin to decompress. Allow your new mattress 24 hours to recover from compression before sleeping on it.

