


Guidelines on choosing the size of a sling

Guidelines on choosing the size of a sling

All dimensions in inches



Size / cm	W1	W2 ^{x)}	W2 ^{xx)}	H
Kids 2-4			18 ¹ / ₈ - 21 ² / ₈	
Kids 4-6	9 ⁷ / ₈ - 11 ⁶ / ₈	21 ⁵ / ₈ - 35 ³ / ₈	19 ⁶ / ₈ - 25 ⁵ / ₈	17 ⁷ / ₈ - 23 ⁵ / ₈
Kids 6-10	11 - 13 ⁶ / ₈	25 ² / ₈ - 41	20 - 28 ⁶ / ₈	21 ⁵ / ₈ - 30 ³ / ₈
Kids 10-14	13 - 15	27 - 42 ² / ₈		26 ⁶ / ₈ - 31 ⁴ / ₈
Kids 10-16			22 - 29 ⁴ / ₈	
XS	13 - 14 ⁵ / ₈	28 ⁴ / ₈ - 44		29 ⁴ / ₈ - 32 ² / ₈
S	14 ¹ / ₈ - 15 ⁶ / ₈	30 - 45 ⁴ / ₈		31 ⁴ / ₈ - 34 ² / ₈
M	15 ³ / ₈ - 16 ⁷ / ₈	31 ⁴ / ₈ - 47 ² / ₈		33 ⁴ / ₈ - 36 ² / ₈
L	16 ⁴ / ₈ - 17 ⁶ / ₈	35 ⁵ / ₈ - 51		35 ³ / ₈ - 38 ² / ₈
XL	17 ⁶ / ₈ - 19 ² / ₈	39 ² / ₈ - 55		37 ³ / ₈ - 40 ¹ / ₈
2XL	18 ⁷ / ₈ - 20 ⁴ / ₈	43 ² / ₈ - 59		37 ³ / ₈ - 40 ¹ / ₈
3XL	21 ² / ₈ - 22 ⁷ / ₈			37 ³ / ₈ - 40 ¹ / ₈
4XL	22 ⁷ / ₈ - 24 ⁷ / ₈			37 ³ / ₈ - 40 ¹ / ₈
5XL	24 ⁴ / ₈ - 28 ⁷ / ₈			37 ³ / ₈ - 40 ¹ / ₈

W2 = Chest measurements

x) Guideline for choosing Active Trainer and Gait Trainer

xx) Guideline for choosing Active Vest Kids